

131 County Rd. 34 E. Jackson MN, 56143 1.800.446.8222 www.eagleplows.com

### **2821 – KAWASAKI MULE 4010**

Use the attached page to help with part identification during installation.

Tools:	
9/16 Wrench	17mm Wrench
9/16 Socket & Ratchet	17mm Socket & Ratchet

### **Plow Mount Installation:**

STEP 1: Remove the front plastic bumper guard and the two front center skid plate bolts and set aside.

**STEP 2:** Slide the rear of the plow mount in between the frame and the skid plate. Place a 3/8 flat washer (Item 5) on each of the M10 x 30mm bolts (Item 9). Insert each of the bolts through the previously opened holes going through the skid plate, plow mount and frame. Place another 3/8 flat washer (Item 5) on the bolts and then start the original factory nuts onto the two bolts. Do not fully tighten.

**STEP 3**: Place a 3/8 flat washer (Item 5) on four of the 3/8 x 1" hex bolts (Item 4) and insert them through the four holes in the front of the plow mount. Start a 3/8 Nylock nut (Item 3) onto each bolt. Do not fully tighten.

**STEP 4:** Place a 3/8 flat washer (Item 5) on the remaining two 3/8 x 1" hex bolts (Item 4) and insert them through the slot on the outside of the plow mount and the front bumper frame and start a 3/8 flat washer (Item 5) and 3/8 Nylock nut (Item 3) onto the end of each bolt. Do not fully tighten.

**STEP 5:** Square the mount up to the machine and then fully tighten all of the hardware working in a criss-cross pattern to keep the mount straight. The front plastic bumper guard may be replaced at this time if desired.

\*NOTE: There will be two extra bolts left over in the hardware kit after installation is complete. The two 3/8 x 1-1/4" bolts are not needed for this mount.

# **Attaching the Push Tube to the Plow Mount:**

**STEP 1:** Roll the UTV over the push tube assembly.

**STEP 2:** Lift the push tube up to the plow mount and line the holes in the ears on the push tube up with the holes in the ears on the plow mount.

**STEP 3:** Insert each of the 3/4 x 2" clevis pins (Item 7) through the holes and secure in place using the hair pin clips (Item 8).

STEP 4: Attach the lift system of choice and the plow is ready for use.

## **Removing the Push Tube from the Plow Mount:**

Reverse the previous steps to remove the push tube. Once the 3/4" pins are removed, place them back into the holes on the push tube assembly with the hair pin clips to prevent them from getting lost when the plow is not in use.

# **Additional Notes:**

- Periodically check all mounting hardware.
- (Optional) Mount the cable stop (Item 2) using the wire clip (Item 6) along the winch cable to prevent interference between the plow system and the machine when the plow is lifted.

HDW1395 Rev. A

# IKI MULE 4010 PLOW MOUNT ATION INSTRUCTIONS

4	HDW123 12 HDW1247 1 HDW1247 1 HDW1260 2 HDW1314 2 HDW1314 2	4	Т
HDW1247	HDW1247 HDW1260 HDW1314 HDW1314		
HDW1260   2   CLEVIS PIIN, 3/4 × 2, ST,ZN     HDW1261   2   HAIRPIIN, 1/8" DIA., 7/16-3/4     HDW1314   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW1314   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW1314   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW1314   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW1314   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW1314   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW1261   2   HAIRPIN, 1/8" DIA., 7/16-3/4     HDW1261   2   HAIRPIN, 1/8" DIA., 7/16-3/4     HDW1314   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW141   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW141   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW141   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW141   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW141   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW141   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW141   2   BOLT, M10-1.25 × 30 HEX 8.8 Z     HDW141   2   BOLT, M10-1.25 × 30 HEX 8.	HDW1260 HDW1314 HDW1314		
HDW1261 2 HAIRPIN, 1/8" DIA, 7/16-3/4 HDW1314 2 BOLT, M10-1.25 X 30 HEX 8.8 Z  MOUNTING HARDWARE IS THE SAME ON THIS SIDE  (2)  (3)  (4)  (5)	HDW1261 HDW1314 HDW1314		
HDW1314   2   BOUT, M10-1.25 X 30 HEX 8.8 Z  MOUNTING HARDWARE IS THE SAME ON THIS SIDE  STATE SAME SAME ON THIS SIDE  STATE SAME SAME ON THIS SIDE  STATE SAME SAME ON THIS SIDE  STATE SAME ON THIS SAME ON THIS SIDE  STATE SAME ON THIS SAME O			
		OM THIS	MOUNTING HARDWARE THE SAME ON THIS SIDE

282									
DESCRIPTION	PLOW MOUNT	CABLE STOP	NUT, 3/8-16 NYLOCK	BOLT, $3/8-16 \times 1.00 \text{ HEX, GR5, Z}$	WASHER, 3/8" FLAT, SAE, Z	3/16 IN WIRE ROPE CLIP	CLEVIS PIN, $3/4 \times 2$ , $ST,ZN$	HAIRPIN, 1/8" DIA., 7/16-3/4	BOLT, M10-1.25 X 30 HEX 8.8 Z
ΩŢ	1	1	9	9	12	1	2	2	2
PART NUMBER QTY	2821-4	3918-4	H17043	HDW/220	HDW1223	HDW1247	HDW1260	HDW1261	HDW1314
ITEM No.	1	2	8	4	2	9	7	8	6